



Product Application & Results

1997 American Blvd. • P.O. Box 5606 • De Pere, WI 54115-5606 • 800.225.2231 • Fax: 920.337.9410

PRODUCT: **Foam-It™ Body Shampoo** **Stock # 1800**

Description: Thick, viscous, liquid foaming detergent with excellent lubricity and cleaning ability.

Color: Purple

Scent: Mild

Foaming Ability: Very High

<u>Features</u>	=	<u>Benefits</u>
Highly concentrate	=	Low cost per car
High viscosity	=	Long-lasting
Good lubricity	=	Reduces cloth friction
High detergency	=	Keeps cloth and lines clean
Easy rinsing	=	No soap left on cars

Applications / Dilution Ratios

<u>Application</u>	<u>Dilution</u>	<u>Ounces</u>
Central Soaper System	1:900	¼ to ½
Foam Generator	1:250	½ to 1
High Pressure Guns	1:400	½ to 1

Guidelines for Application

Clean tank, lines, nozzles, etc. of previous product for best results. More air to the foamers provides fluffier foam; less air provides wetter foam.

Water Quality: Soft water will provide best results, but **Foam-It™** works very well in hard water too!

Solution Temperatures: Most systems will generally apply the product with cold water, but better cleaning will be achieved with warm or hot water.

PRODUCT:

Foam-It™ Body Shampoo

Stock # 1800

Special Instructions

Through a Dema Valve injector it may be most effective to pre- dilute **Foam-It™** before the Dema to get the best effect with a reduced cost per car.

We **do not** recommend using this product in conjunction with **UltraClear™** or **Advantage®** in reclaim systems. The reclaim abilities of these products will be negated.

This formula performs better in hard water than many competitive products.

Alternative Products

SuperSlick® is a high Lubricity replacement that stops grabbing and squeaking on foam type materials.

AquaFoam® is a high foaming body shampoo designed for use in hard water.

Low pH Sensation® is a high quality foaming detergent that will neutralize alkalinity from any presoak application and help produce a drier car.

UltraClear™ was formulated for friction systems with reclaim systems. It does not foam as much, but will keep cloth and brushes cleaner while settling particles from reclaim systems.

Titration Chart For Foam-It Body Shampoo	Dilution	Drops
	Titrant #1	
	1 to 80	29
	This chart uses "Anionic Titrant"	
	1 to 100	26
	1 to 150	19
	Sample size = 1 tube	
	1 to 200	15
	1 to 300	11
	Titrant #2	
	1 to 400	22
	1 to 500	18
	1 to 600	15
	1 to 700	13