



Product Application & Results

1997 American Blvd. • P.O. Box 5606 • De Pere, WI 54115-5606 • 800.225.2231 • Fax: 920.337.9410

PRODUCT: Spectrum[®] Low Pressure Presoak Stock # 1300

Description: An effective, highly concentrated, deep cleaning low-pressure detergent. Begins the deep cleaning process that is followed by the high pressure detergent application.

Color: Amber

Scent: Fresh Lemon

Foaming Ability: Moderate to High

<u>Features</u>	=	<u>Benefits</u>
Good Foamer	=	Customer appeal.
Clean Fragrance	=	More customer appeal.
Good Cleaner	=	Produces results.
Not Harsh	=	Easy on equipment and people.
Titratable	=	Quickly determine dilution ratio

<u>Application</u>	<u>Dilution Ratios</u>		
<u>Self-Serve Systems</u>	<u>Strongest</u>	<u>Weakest</u>	<u>Average</u>
Foam or Spray - Low-pressure presoak	1:60	1:100	1:80

Required strength of product dilution will vary depending on cleaning conditions and type and condition of equipment used.

Guidelines for Application

Water Quality: Use SOFT WATER for best performance! In hard water (over 0 grains) increase strength by 10% for each grain of water hardness (1:60 + 10% = 1:54). Trying to clean in frictionless washes with water over 2 grains of hardness is not recommended.

Solution Temperatures: Most self-serves will use cold water, but cleaning will improve if applied with warm (100-120°F) water. Warm water is especially recommended in colder weather.

Dwell time: Allow a minimum of 30 seconds prior to following with either a high-pressure wash or high pressure rinse.

Special Instructions: When a self serve uses one product for low pressure presoak and tire cleaner use Spectrum[®] Low Pressure Presoak between 1:30 and 1:40.

PRODUCT: Spectrum[®] Low Pressure Presoak Stock # 1300

Alternative Products

Spectrum[®] Bright Purple Presoak A similar product but with a bright purple color and fruity scent.

Ultra Spectrum[®] Low Pressure Presoak A high concentrated presoak with a blue color and a Green Apple scent.

The Option[®] Low cost alkaline presoak apply at a dilution between 1:75 and 1:125

Horizon[™] A high foaming and scented frictionless detergent. Use at about 1:150

Advantage[®] or Performix[®] Premium alkaline presoaks with reclaim settling abilities.

Titration Chart For Spectrum[®] Low Pressure Presoak		
This chart uses the "Standard Alkaline Titrant" and a water blank must be titrated to subtract from your total drops before comparing to the curve.	Dilution	Drops
	1:40	20
	1:50	16
	1:60	13
	1:70	11
	1:80	10
	1:90	9
	1:100	8