



Product Application & Results

1997 American Blvd. • P.O. Box 5606 • De Pere, WI 54115-5606 • 800.225.2231 • Fax: 920.337.9410

PRODUCT: Lustra™ Foaming Conditioner

Blue: Stock # 2502 Yellow: Stock # 2504 Red: Stock # 2514

Lustra™ Foaming Conditioner with Cherry Scent

Red: Stock # 2565 Yellow: Stock # 2566 Blue: Stock # 2567

Description: A liquid pre-sealant conditioner that produces a thick, rich, colored foam. Apply prior to a high-pressure sealant or may be used as a colored body shampoo in short friction tunnels. It will not bead water on vehicle surfaces.

Color: Dark Blue, Red and Yellow

Scent: Available Unscented or with Cherry Scent.

Foaming ability: High

Features

Rich colored foam

Cherry Scented Available

Quick foam dissipation

Highly concentrated

Benefits

= Customer appeal

= More Customer appeal.

= Rinses easily

= Low cost per car

Applications / Dilution Ratios

In foam generators dilute **Lustra™ Foaming Conditioner** between 1:200 and 250 (1 to 1.5 ounces per car). Adjust air and water to suit conditions.

Guidelines for Application

Water Quality: Soft water is recommended for best results. In hard water increase strength to achieve desired results.

Solution Temperatures: Generally cold water is used in this application, however warm water is acceptable.

Economy: Adjust dilution ratio to suit conditions. Mix with soft water.

PRODUCT: Lustra™ Foaming Conditioner

Blue: Stock # 2502 Yellow: Stock # 2504 Red: Stock # 2514

Lustra™ Foaming Conditioner with Cherry Scent

Red: Stock # 2565 Yellow: Stock # 2566 Blue: Stock # 2567

Special Instructions

Lustra™ Foaming Conditioner can also be used as a colored foam detergent. It has a high level of detergency and performs excellent in friction systems.

Alternative Products

Ultra Concentrated Lustra™ Foaming Conditioner for use where space is limited and/or use of an ultra concentrate is preferred.

Lustra™ Foaming Polish also produces colored foam that rinses easier and it does bead water on vehicle surfaces, foams slightly less.

Titration Chart for Lustra™ Foaming Conditioner - Yellow		
This chart uses the " <u>CSI® Anionic Foamer Titration Kit</u> ". Sample Size = One sample tube	Dilution	Drops
	Use Titrant #1	
	1:50	24
	1:100	13
	1:150	10
	1:200	9
	1:250	8
	1:300	7